




RSWIG

46

RSWIG/355	L 355	A1 265
RSWIG/635	L 636	A1 548




Achtung:
Leuchte nicht öffnen!
Garantieverlust!


Attention:
Don't open the luminaire!
Loss of Guarantee!

Attention:
N'est pas ouvrir le luminaire!
Perte de garantie!


Atención:
Non abrir la luminara!
Pérdida de garantía!




Montage





Demontage



rason DALI



- Ein / Aus / Dimmen -
- On / Off / Dimming -



- Ein / Aus / Tast-Dim -
- On / Off / Touch dim -

